

ALKOTA MODEL 5357

SPECIFICATIONS

PERFORMANCE

DISCHARGE VOLUME.....5.0 GPM / 18.9 LPM
PUMP HEAD PRESSURE.....3500 PSI / 241 BAR
TEMPERATURE RISE.....130°F @ 5.0 GPM / 54°C @ 18.9 LPM
TEMPERATURE LIMIT.....UP TO 200 DEGREES

COMBUSTION SMOKE/BACHARACH SCALE.....#1 OR #2 SMOKE
CARBON MONOXIDE ALLOWED.....0.01%
HEAT INPUT.....548,800 BTU/HR / 138,298 KgCAL/HR
DRAFT/STACK INSTALLATION.....0.2" - 0.04" WC READING

GENERAL

MINIMUM WATER INLET PRESSURE.....40 PSI / 0.68 BAR
SPRAY TIP.....(#4.25-15DEG) P/N J00-15042-2
HOSE, HIGH PRESSURE.....3/8" X 50' P/N K02-03150C9
WAND P/N J06-00104E
BELT, V - ENGINE TO PUMP..... P/N R02-00746
BELT, V - ENGINE TO GENERATOR..... P/N R02-00237
CABLE, BATTERY - POSITIVE..... P/N F05-00231
BATTERY, CABLE - NEGATIVE..... P/N F05-00242
THERMOMETER..... P/N Y01-00017
COIL SIZE.....1/2"ID X 158' SCHEDULE 80 - P/N 4205A-00111
COIL BACK PRESSURE (NEW).....5 PSI @ 5.0 GPM / 0.34 BAR @ 18.9 LPM
COIL BACK PRESSURE REQUIRING DESCALING.....50 PSI @ 5.0 GPM / 0.34 BAR @ 18.9 LPM

WEIGHT (DRY).....960 LBS / 435 KG
FUEL TANK CAPACITY.....2.7 GAL / 10 L
FUEL TANK CAPACITY.....9.5 GAL / 36 L
HOSE - PUMP TO UNLOADER.....P/N K02-03222A2
HOSE - UNLOADER TO COIL.....P/N K02-03248A2
HOSE - GAUGE FROM UNLOADER.....P/N K02-02224A2
GAUGE, PRESSURE - 5000 PSI.....P/N Y01-00015
DIMENSIONS.....L-54", H-46", W-45"
THERMOSTAT, PROBE.....P/N F04-00856
TRIGGER GUN..... P/N J06-00158-B

PUMP

PUMP(TS1021) P/N N09-00060

BUSHING, PULLEYP/N R04-00001
PULLEYP/N R03-75100

UNLOADER

UNLOADERP/N C07-03800

VALVE, SAFETYP/N C03-00518

PUMP ENGINE

LAMBARDINI - 23.4 HP / 17.5 KW.....P/N F05-00396
LIQUID COOLED DIESEL
SPEED.....3240 RPM
CHARGING SYSTEM.....40 AMP

AIR CLEANER.....P/N F05-00485-03
PRE-CLEANER OIL FILTERP/N F05-00485-02
BUSHING, PULLEYP/N R04-00002
PULLEYP/N R03-00747

ELECTRICAL

VOLTAGE.....12 VDC
SWITCH, FLOW.....P/N F04-00789
BATTERY SIZE.....GROUP 24

GENERATOR 115V.....P/N F05-00112
PULLEYP/N 4205-00162
SCREW, SET - GENERATOR PULLEY.....P/N H04-31305

BURNER

BURNER.....P/N V00-173179-2
SPEED.....3450 RPM
FUEL NOZZLE.....(3.50 80 DEGREE B) P/N V3.50 80DB
FUEL CONSUMPTION.....3.92 GPH / 14.8 LPHR
FUEL PRESSURE125 PSI / 8 BAR

MOTOR - .1/5 HP..... P/N V00-20554
VOLTAGE.....115V 1PH 60HZ
FUEL PUMP(DAN FOSS) P/N V-100714-001
TYPE.....PRESSURE ATOMIZING
FUEL TYPE..... #1 OR #2 DIESEL

MACHINE RECORD

SERIAL NUMBER

MAINTENANCE RECORD

DATE OF PURCHASE

PLACE OF PURCHASE

NOTES:

5357 - OPERATION TABLE OF CONTENTS

OIL FIRED ENGINE DRIVEN CLEANER

SAFETY INSTRUCTIONS

Page Number

• Safety Symbols	3
• General	3
• Mechanical	4
• Electrical	4
• Fuel	4

INSTALLATION

• Location	5
• Electrical	5
• Extension Cord	5
• Venting	5
• Water Supply	5
• Barrier	5
• Water Conditions	5
• Freezing	5
• Cold weather	5
• Chemicals	5

OPERATION

• Pre Start-Up	6
• Start-Up	6
• To Clean, Apply Chemical, To Rinse	7
• Shut Down	7
(OPTIONAL) Combination Instructions	8

MAINTENANCE

Machine

• Flushing, Storage	9
• Spray Tip Maintenance	9
• Belt Tension	10
• Coil Back Pressure	10
• Schedule	11

Burner

• Fuel Pump Filter	See Parts List Section
• Transformer Check	See Parts List Section
• Burner Gun Remove/Replace	See Parts List Section
• Blower Fan Remove/Replace	See Parts List Section

Fuel Filter

See Parts List Section

TROUBLESHOOTING

Page Number

• Machine	12, 13
• Water Heater	14
• Oil Burner	See Parts List Section
• Pump	See Parts List Section
• Fuel Filter	See Parts List Section

SERVICE

• Pump	See Parts List Section
• Fuel Filter	See Parts List Section
• Trigger Gun	See Parts List Section
• Unloader	See Parts List Section

COMPONENT ADJUSTMENT

Burner

• Air Band Adjustment	See Parts List Section
• Buss Bar Alignment	See Parts List Section
• Electrode Ass'y Adjustment	See Parts List Section

Chemical Metering Valve

See Parts List Section

Temperature Control (If So Equipped)

See Parts List Section

Unloader Valve

See Parts List Section

PUMP OIL CHANGE

RECORD

See Parts List Section

WARRANTY

Inside Back Cover

SPECIFICATIONS

1

SAFETY, INSTALLATION, AND OPERATION

ENGINE DRIVEN OIL FIRED CLEANER

MACHINE UNPACKING

ALL CLEANERS ARE CAREFULLY INSPECTED AND CARTONED TO PROTECT AGAINST SHIPPING DAMAGE. IF THERE IS DAMAGE OR MISSING PARTS, THE TRANSPORTATION COMPANY AGENT SHOULD MAKE A NOTATION TO THAT EFFECT ON THE BILL. REFER TO THE PARTS LIST IN THIS MANUAL AND ADVISE WHAT PARTS ARE MISSING OR DAMAGED. IF AVAILABLE, GIVE THE INVOICE NUMBER ON ALL ORDER BILLS. THIS PROCEDURE WILL ENABLE NEEDED PARTS TO BE SHIPPED QUICKLY.

READ ALL Installation, Operation, and Maintenance instructions before operating the machine

NOTE: Refer to CLEANER MODEL for **SERIAL NUMBER** location

NOTE: Dimensions are in inches unless otherwise noted

IMPORTANT SAFETY

INSTRUCTIONS

 The safety alert symbol. This symbol is used to identify safety information about hazards that can result in personal injury. A signal word (DANGER, WARNING, or CAUTION) is used with the alert symbol to indicate the likelihood and the potential severity of injury. In addition, a hazard symbol may be used to represent the type of hazard

 **DANGER** indicates a hazard which, if not avoided, **will result in death or serious injury.**

 **WARNING** indicates a hazard which, if not avoided, **could result in death or serious injury.**

 **CAUTION** indicates a hazard which, if not avoided, **might result in minor or moderate injury.**

CAUTION, when used **without** the alert symbol, indicates a situation that **could result in damage to the equipment.**

GENERAL SAFETY

1. Before operating this machine, read and observe all safety, unpacking, and operating instructions. Failure to comply with these instructions could create a hazardous situation.
2. The operator of this equipment should not operate this equipment when fatigued or under influence of alcohol or drugs.
3. The operator of this equipment should be thoroughly familiar with its operation and trained in the job to be accomplished.
4. The operator of this equipment should wear protective face shields and other protective clothing as required for safe operation.
5. Keep all protective covers and shields in place. Operating this machine with moving parts could allow operator or bystander serious injury or even death.
6. Do not operate the machine if any mechanical failure is noted or suspected. Keep all shields in place.
7. Do not leave this machine unattended when it is operating.
8. All installations must conform to all applicable local codes. Contact your electrician, plumber, utility company or seller for details.
9. If a water leak is found, **DO NOT OPERATE THE MACHINE.** Shut off the engine and repair.
10. Follow instructions on how to stop the machine and bleed pressures quickly. Be thoroughly familiar with the controls.
11. When starting a job, survey the area for possible hazards and correct before proceeding.
12. If chemicals are used in conjunction with this equipment, read and follow the product label directions.
13. During normal operation of this machine, hot discharges and surfaces may be produced. Avoid burns by being aware of these areas and staying clear of them during and immediately following equipment operation.
14. Do not start the burner unless a full flow of water is coming from the gun. Air leaks or insufficient water to the machine, or an open chemical valve means less than full flow of water through the coil. This could cause hose failure and burns to the operator.

15. Do not start the machine unless the gun assembly is firmly gripped by the machine operator. Failure to do this could result in injury from a flying hose and gun assembly.

 **WARNING:** RISK OF INJECTION OR SEVERE INJURY. KEEP CLEAR OF NOZZLE. DO NOT DIRECT DISCHARGE STREAM AT PERSONS. THIS EQUIPMENT IS TO BE USED ONLY BY TRAINED OPERATORS.

 **AVERTISSEMENT:** RISQUE D'INJECTION ET DE BLESSURES GRAVES. SE TENIR À L'ÉCART DU JET. NE PAS DIRIGER LE JET DE SORTIE VERS D'AUTRES PERSONNES. CONFIER L'UTILISATION LE JET DE SORTIE VERS D'AUTRES PERSONNES. CONFIER L'UTILISATION DE CE MATÉRIEL À UN

16. Always point the gun assembly in a safe direction and do not direct spray on the cleaner or personnel in the area.

 **WARNING:** OPEN FLAME. Do not operate this machine in an area with combustible materials. A suitable fire extinguisher should be available in operating area.



17. Always shut down machine before refueling.

18. Do not overfill the fuel tank. If any spillage occurs, clean up immediately and/or neutralize the spill before attempting to operate the machine.

MECHANICAL SAFETY

1. All guards, shields, and covers must be replaced after adjustments are made to prevent accidental contact with hazardous parts.
2. Drive belts must be inspected and tightened periodically to operate at optimum levels.
3. Inspect machine for damaged or worn components and repair or replace to avoid potential hazards. Do not operate the machine if any mechanical failure is noted or suspected.
4. Always use the correct size spray tip found in the GENERAL section of the **MODEL SPECIFICATIONS** or **MODEL EXPLODED VIEW**.

5. **DO NOT** start the engine until you have observed all safety and operating instructions found in the engine manual..

FUEL SAFETY

1. Use only #1 or #2 diesel fuel for the water heater burner. The use of incorrect fuel may result in fire or explosion and severe injury to the operator.
2. Do not refuel machine while it is running or hot. Allow it to cool sufficiently to prevent ignition of any spilled fuel. Clean up any spilled fuel before resuming operation.
3. Fuel burning equipment must have proper ventilation for cooling, combustion air, and exhausting of combustion products.

 **WARNING:** DO NOT USE GASOLINE, CRANKCASE DRAININGS, OR OIL CONTAINING GASOLINE OR SOLVENTS.

 **AVERTISSEMENT:** NE PAS UTILISER D'ESSENCE DE PRODUITS DE VIDANGE NI D'HUILE CONTENANT DE L'ESSENCE OU DES SOLVANTS

4. Stacking, where required, must be installed in accordance with all local codes. A draft diverter must be installed on a machine connected to an exhaust stack to prevent improper operation. (See GENERAL section of **MODEL SPECIFICATIONS** for stack size).
5. Where stacking is not required, provide adequate ventilations to prevent any possible accumulation of hazardous fumes.
6. Personnel trained in and familiar with the type of equipment being serviced should only perform adjustments to fuel burning equipment.

SAVE THESE SAFETY **INSTRUCTIONS**

INSTALLATION

This machine emits **CARBON MONOXIDE**, a **DEADLY GAS**, and must be vented if used in an enclosed area. Improper venting can cause poor combustion, delayed ignition, down drafts, and the possibility of freezing the coil. Contact your distributor or local heating and air conditioning dealer for proper materials. Local codes must be observed.

1. **VENTILATION:** Oil fired machines that must be vented. See the VENTING section of this manual. Where stacking is not required, provide adequate ventilations to prevent any possible accumulation of hazardous fumes.
2. **FIRE HAZARD:** Keep combustible materials away from oil machines. **DO NOT** allow lint or dust to collect in the burner area.
3. **BARRIER:** We recommend a barrier be installed between the machine and wash area to prevent moisture from coming in direct contact with electrical controls and engine. This will increase the machine's life and lessen electrical problems.
2. **WATER SUPPLY:** This machine must have a water supply meeting or exceeding the maximum discharge volume specified in the machine specifications, and a minimum water inlet pressure of 40PSI / 12.1KGM.
7. **WATER CONDITIONS:** Local water conditions affect the coil adversely more than any other element. In areas where troublesome conditions may exist with like equipment (such as water heaters), we recommend the use of a water softener.
8. **FREEZING:** This machine must be protected from freezing according to STORAGE section of **MACHINE MAINTENANCE**.
9. **COLD WEATHER:** As the weather becomes colder, fuel becomes thicker and may become so viscous that the fuel will not flow properly. As viscosity increases, the thicker oil can cause delayed ignition, poor spray patterns, and rumbling fires. As moisture will quickly destroy fuel pumps, make certain that tank openings are secure and moisture cannot enter. In cold weather areas, frost build up will occur in fuel tanks. As the weather warms it turns to condensate, and the water will be in the tank. Keep the tank clear of water, as moisture reaching the fuel pump will cause rust, and the pump will bind. A full fuel tank will lessen condensation build up.

10. **CHEMICALS:** Mix chemicals per the chemical manufacturers printed directions. Follow all mixing, handling, application, and disposal instructions. Wear gloves, boots, goggles, and protective clothing appropriate for the chemical being used

VENTING

DANGER: This machine emits carbon monoxide, and deadly gas, and **MUST NOT** be used in an enclosed or confined area.

DANGER: Engine exhaust gases contain poisonous carbon monoxide. Carbon monoxide is odorless, colorless, and can cause death if inhaled. Avoid inhaling gas fumes. Engine **MUST NOT** be used in an enclosed or confined area.



**DANGER: CARBON
MONOXIDE HAZARD**



OPERATING INSTRUCTIONS

PRE START-UP

1. The first time the machine is operated, after repairs have been made, or if the machine has set for a period of time (30 days or more) follow the following procedures.
 - A. Check the tension of the belt (if so equipped) per instructions in **MACHINE MAINTENANCE**.
 - B. Flush the machine per instructions in **MACHINE MAINTENANCE**.
 - C. Install float tank drain plug (if so equipped).
 - D. Open float tank ball valve (if so equipped).
- " **CAUTION:** Always use the factory supplied pressure wash hose with your machine.
- " **DO NOT** substitute any other hoses as a potential safety problem may develop.
- " **CAUTION:** If machine has been exposed to sub-freezing temperatures, it must be thoroughly warmed to above freezing before operating. Failure to warm machine can cause damage to the pump packings and other components.
2. Read and observe all items in "CLEANER INSTALLATION".

START-UP

- ♦ Refer to the **MAINTENANCE SCHEDULE** for any maintenance to be performed before operation.
- ♦ This machine emits carbon monoxide, a deadly gas, and must be vented if used in an enclosed area.




**DANGER: CARBON
MONOXIDE HAZARD**




- ♦ **OIL LEVEL:** Check the oil level in the water pump, the gear case (if so equipped), and the engine.
- ♦ **BELT** (if so equipped): Make sure the belt tension and condition is as specified in **MACHINE MAINTENANCE**.

- ♦ **METERING VALVE** (if so equipped): Make sure the metering valve is closed before operation. If air enters the system through this valve, poor performance and machine damage will occur. Refer to the metering valve insert for proper operation.
- ♦ **FUEL FILTER:** Inspect the fuel filter for any evidence of water contaminants.
- ♦ **FUEL:** Make sure the fuel lines are open (**CAUTION:** Closed fuel valves will **DAMAGE** the fuel pump and void warranty) and fuel is the type specified in the **BURNER** section of **MODEL SPECIFICATIONS**
- ♦ **FUEL QUANTITY:** Make sure the fuel supply is sufficient to complete the job. See the **GENERAL** section of the **MODEL SPECIFICATIONS** for the fuel tank capacity.
- ♦ **WATER SUPPLY:** This machine must have a water supply meeting or exceeding the maximum discharge volume specified in the machine specifications, and a minimum water inlet pressure of 40PSI / 12.1KGM.
- ♦ **LIME:** Water containing large amounts of lime, calcium or other similar materials can produce a coating on the inside of the impact nozzle or spray tip and coil pipe.
- ♦ **FLOAT TANK:** Check the float tank to assure it is full and the float tank valve shuts off securely.
- " **BALL VALVE:** Check the position of the ball valve (if so equipped) on outlet line of the float tank assuring that it is in the open position.

OPEN



CLOSED



WARNING: RISK OF INJECTION OR SEVERE INJURY. KEEP CLEAR OF NOZZLE. DO NOT DIRECT DISCHARGE STREAM AT PERSONS. THIS EQUIPMENT IS TO BE USED ONLY BY TRAINED OPERATORS.

A V E R T I S S E M E N T : R I S Q U E D'INJECTION ET DE BLESSURES GRAVES. SE TENIR À L'ÉCART DU JET. NE PAS DIRIGER LE JET DE SOTIE VERS D'AUTRES PERSONNES. CONFIER L'UTILISATION LE JET DE SOTIE VERS D'AUTRES PERSONNES. CONFIER L'UTILISATION DE CE MATÉRIEL À UN OPÉRATEUR QUALIFIÉ.

1. Select temperature (if so equipped).
2. With the gun assembly in hand (on trigger gun models hold the trigger gun valve in open position) and with a good flow of water start the engine per engine owner's manual.

CAUTION: A good flow of water must be Flowing from the end of a gun for 30 seconds, before proceeding. Lack of water can cause damage to the water pump and like components.

CAUTION: On a machine equipped with a trigger gun valve, if the trigger gun valve remains in the closed position for more than 3 minutes, water pump damage may occur.

4. Turn the burner switch on.

CAUTION: Do not run the machine with the burner switch in the on position when the fuel tank is empty or with tank valves closed. This will cause damage to the fuel pump and void warranty.

CAUTION: Do not operate with the trigger gun valve closed for more than 3 minutes or water pump damage may occur.

5. To **CLEAN:**

- A. Start on the lower portion of the area to be cleaned and work up using long, even, overlapping strokes.
- B. Dirt is generally removed easily if grease and/or oil is not present. However if grease

and/or oil are present, hot water and chemical will accelerate in the cleaning process.

6. **TO APPLY CHEMICAL:**

CHEMICAL: Use factory recommended chemicals for best cleaning action and for extended pump life. Contact your dealer for chemicals available. Follow instructions on chemical container.

Mix chemicals per label instructions. Use necessary safety precautions.

- A. Insert chemical screen into chemical container
- B. Adjust metering valve (if so equipped).
- C. If the gun assembly is equipped with variable or multiple nozzle assembly, adjust as desire.

7. **TO RINSE:**

- A. If the machine is equipped with a panel mounted metering valve, close the chemical metering valve (if so equipped). NOTE: It is advisable to dip the chemical screen in a container of clean water and open the valve 1 minute to clean the valve of any remaining residue.
- B. If the gun assembly is equipped with variable or multiple nozzle assembly, open and close to clean nozzle of any remaining residue.
- C. After a clear flow of water is noted from the end of the wand, start from the top, working downward using long, overlapping strokes.

SHUT-DOWN

1. Turn the burner switch to the off position. (If not already done so in the cold water rinse.)
2. After cool, clear water is coming from the end of the wand, turn off the engine.
3. Turn off the water supply.
4. If freezing conditions may exist, refer to STORAGE in **MACHINE MAINTENANCE**.
5. Replace stack cover (if so equipped).

COMBINATION OPTION

INSTRUCTION

⚠ WARNING: This machine should be operated only by personnel instructed in and familiar with its operation. The discharge produced is 300°F / 150°C and can cause **SERIOUS BODILY INJURY** to you and anyone coming in contact with it.

NOTE: In process of making steam, the water flow through the coil has to be decreased. The amount of water is determined by the pressure and water temperature of your location.

If the incoming water temperature is as high as 70°F, the amount of water going through the coil has to decrease very little.

If the incoming water temperature is as low as 40°F, the amount of water going through the coil has to be decreased quite a bit.

The water temperature is relative to the season variation and should be taken in consideration when operating steam.

1. Install the open gun assembly.
2. Open the ball valve on coil inlet assembly.
3. Set the temperature control to 300°F MAXIMUM.
4. For startup see "START UP" section of this manual

5. Turn the burner switch on.

CAUTION: Do not run the machine with the burner switch in the on position when the fuel tank is empty. This will cause damage to the fuel pump and void warranty.

CAUTION: Do not operate with the trigger gun valve closed for more than 3 minutes or water pump damage may occur.

6. To **CLEAN**:

A. Start on the lower portion of the area to be cleaned and work up using long, even, overlapping strokes.

B. Regulate the temperature indicated on the thermometer to 300°F by turning the regulating valve on the coil inlet assembly clockwise to DECREASE the temperature and counter clockwise to INCREASE the temperature.


C. To RINSE:

D. Turn off the burner.

E. After a clear flow of water is noted from the end of the wand, start from the top, working downward using long, overlapping strokes.

SHUT-DOWN

1. Turn the burner switch off. (If not already done so in the cold water rinse.)
2. After cool, clear water is coming from the end of the wand, turn off the engine.
3. Turn off the water supply
4. Close the ball valve on the coil inlet assembly.
5. Replace the stack cover (if so equipped)
6. If freezing conditions may exist, refer to STORAGE in **MACHINE MAINTENANCE**.
7. Replace stack cover (if so equipped).



MACHINE MAINTENANCE

GAS ENGINE DRIVEN OIL FIRED CLEANERS

FLUSHING

1. Connect machine to a pressurized water supply meeting the requirements specified in the GENERAL section of the **MODEL SPECIFICATIONS**.
2. Turn on the water supply.
3. Check the float tank (if so equipped) to assure it is full and the float valve shuts off securely.
4. Check the position of the ball valve (if so equipped) on outlet line of the float tank assuring it is in the open position.
5. Remove spray tip from gun assembly.
6. With gun assembly in hand, start the engine. On trigger gun models hold the trigger gun valve in open position.
CAUTION: DO NOT RUN PUMP WITHOUT WATER, AS THIS WILL CAUSE DAMAGE TO THE PUMP AND VOID WARRANTY.
7. When clean water flows from gun, turn off the switch.
8. Reinstall spray tip.
9. With gun assembly in hand, start the engine. On trigger gun models hold the trigger gun valve in open position.
10. When clean water flows from gun, turn off the engine.
11. If freezing conditions may exist, refer to "STORAGE" section.
12. Turn off and disconnect the water supply.

STORAGE

1. To prevent the fuel tank rusting from condensation, drain and flush with clean fuel. Do not use gasoline or water. Refill with proper fuel.
2. Rinse the Soap Line by inserting the screen into a container of clear water and open the metering valve 1 minute to clean it of any remaining residue. Be sure chemical metering valve is closed when finished.
3. Disconnect the water supply.
4. Remove the spray tip nozzle from gun assembly and wire to machine.

5. Check the position of the ball valve (if so equipped) on the outlet of the float tank assuring it is in the closed position.
6. Attach an air chuck to the air valve stem on the pump assembly. With the trigger gun in the open position, apply air until a mixture of air and very little water is coming from the gun wand. Then turn on the burner and depress the vacuum switch. Run it for 45 seconds allowing any remaining water to turn to steam. Do not remove air until after the burner is off.
7. Fill a 1-gallon container with Ethylene Glycol type antifreeze. Minimum should be a mixture of ½ antifreeze and ½ water strength before each use, as the antifreeze will dilute with each use.
8. Install a 2-ft. Garden hose to the water inlet. Insert the other end into a container of antifreeze solution.
9. With the discharge gun assembly in hand, start the engine. On trigger gun models hold the trigger gun valve in open position.
10. Turn off the switch just prior to running out of antifreeze mixture.
11. Disconnect electrical supply.
12. Disconnect gun and hose.
13. Place machine in a dry place protected from weather conditions.


SPRAY TIP MAINTENANCE

1. Remove the spray tip from the gun assembly.
2. Blow out debris with compressed air from the outside in. Any debris remaining in the inlet side of the nozzle should be cleaned out. If lime or chemical scale is present in the inlet side, the nozzle may be soaked in descaling solution or replaced. If the tip is worn, replace with one specified in the GENERAL section of **MODEL SPECIFICATIONS** or **MODEL EXPLODED VIEW**.
3. Before replacing spray tip flush the machine per "FLUSHING" section.
4. Reinstall Spray tip to gun assembly.

MACHINE MAINTENANCE CONT'D

GAS ENGINE DRIVEN OIL FIRED CLEANERS

BELT TENSION



1. Correct belt tension will allow a 1/64-inch deflection for each inch of span between pulley centers with a 6-pound force applied in the middle of the span. EXAMPLE: A 6-pound force applied at the middle of an 8 inch span should produce a deflection of 8/64 inch or 1/8 inch.
2. Belts can be tightened or loosened by loosening the nuts holding the pump assembly to the motor mount. Then tighten or loosen the j-bolt on the motor mount. Retighten the pump assembly after the desired tension is reached.

COIL BACK PRESSURE CHECK



Above is a cross section view showing the progressive liming of coils.

A regular maintenance schedule for descaling your heating coil is essential to insure its longevity.

The frequency of descaling depends upon the amount of use and the condition of the water.

1. Check the condition of your water pump and unloader valve.
2. Install a pressure gauge between the water pump and coil inlet as specified below.

COIL BACK PRESSURE CHECK INSTRUCTIONS

DISCHARGE VOLUME

GPM

2-3 GPM
3-4 GPM
4-5 GPM
6 GPM
8-10 GPM

BACK PRESSURE

REQUIRING DESCALING

50 PSI
75 PSI
100 PSI
150 PSI
175 PSI

USE A 1000 PSI GAUGE

4. Remove the hose and gun assembly from the coil outlet.
5. Turn on the water supply. Check the float valve (if so equipped) to assure float tank is full and the float valve shuts off securely.
6. Check the position of the ball valve (if so equipped) on outlet line of the float tank assuring it is in the open position.
7. Start the engine. If the coil back pressure reading is above that found in the GENERAL section of the **MODEL SPECIFICATIONS** then your machine needs to be descaled.

A separate descaling pump is recommended so scale and other chemicals will not come in contact with your water pump and causes premature wear.

NOTE: Contact your local dealer for descaling of your unit.

7. Disconnect the water supply.
8. Disconnect the electrical supply.
9. Reinstall the hose and gun assembly.
10. Remove the pressure gauge.

ACCESSORIES

PART NO.

DESCRIPTION

Y02-00001 0-1000 PSI (69 BAR) Pressure Gauge
Z01-00070-1..... 3/8" x 100 Yards Thread Tape

NOTE: All Gauges are Glycerin Filled—1/4 NPT

MACHINE MAINTENANCE

ENGINE DRIVEN OIL FIRED CLEANERS	DAILY	EACH HR FIRST 8 HRS	AFTER FIRST 50 HRS	EVERY 50 HRS	EVERY 100 HRS	EVERY 500 HRS	YEARLY
OIL BATH WATER PUMP: Oil Level – check and add as needed per PUMP SERVICE insert. Oil Change – drain and refill per PUMP SERVICE insert. CAUTION: Used oil must be disposed into an environment safe container and brought to an oil recycling center. Oil Contamination – Milky color indicates water	●		●			●	
HOSES: Blistering, Loose Covering Abrasion of cover exposing reinforcement. Cuts exposing reinforcement	● ● ●						
BELTS: Cracks or fraying Belt Tension - For correct belt tension, see MACHINE MAINTENANCE insert.	● ●						
FILTER – WATER: Check water inlet hose screen for debris Check float tank screen for debris	●	●		●			
SPRAY TIP: Check Tip for debris.	●						
FUEL: Adequate fuel supply.	●						
FILTER—FUEL: If contaminants are present see FUEL FILTER insert. Remove and Replace fuel filter per FUEL FILTER insert.	● ●						
SCREEN—FUEL: Check fuel pump screen for debris see OIL BURNER MAINTENANCE insert.					●		
BURNER NOZZLE: Replace Nozzle as specified in BURNER section of MODEL SPECIFICATIONS or BURNER ASSEMBLY insert.							●
GUARDS AND SHIELDS: Check that all guards and shields are in place and secure.							●
ENGINE: Check oil level per engine manual. Fill fuel tank. Check air cleaner for dirty, loose or damaged parts. Service pre-cleaner element Service air cleaner	● ● ●		●	●			

CLEANER TROUBLESHOOTING

GAS ENGINE DRIVEN HOT WATER CLEANERS

TROUBLE	POSSIBLE CAUSE	REMEDY
1. Poor Cleaning Action.	A. Hard water. B. Low Pressure. C. Little or no chemical being drawn. D. Improper chemical. E. Improper chemical mixture F. Low discharge pressure.	A. Connect machine to water softener. B. See "Low operating pressure" C. See "Machine will not draw chemical". D. Obtain proper chemical. E. Mix chemicals per the label. Follow all mixing, handling, application, and disposal instructions. F. See "Low operating pressure"
2. Machine will not draw chemical.	A. No chemical solution. B. Metering valve not open. C. Chemical line strainer clogged. D. Air leak in chemical line. E. Metering valve clogged. F. Restrictor orifice too large or missing.	A. Replenish supply. B. Turn metering valve knob to open. C. Remove screen and clean. D. Tighten all fittings and hoses for the chemical line. E. Disassemble and clean. F. Install proper size orifice.
3. Low operating pressure	A. Insufficient water supply. B. Incoming water hose too small. C. Water supply hose too long. D. Belt slippage. E. Worn Belt. F. Spray tip worn or wrong size. G. Dirty or worn check valves in water pump. H. Water supply hose kinked. I. Inlet filter screen clogged. J. Engine runs slow. K. Air leak in inlet plumbing. L. Defective water pump. M. Leaking discharge hose. N. Chemical metering valve open and sucking air. O. Defective unloader valve P. Inlet ball valve not fully open (if so equipped) Q. Restricted coil	A. The water supply must meet or exceed the maximum discharge volume specified in the PERFORMANCE section, and minimum water inlet pressure specified in the GENERAL section of the MODEL SPECIFICATIONS section. B. Use larger water supply hose. C. Use shorter water supply hose. D. Tighten belt per instructions in MACHINE MAINTENANCE insert. E. Replace belt per CLEANER EXPLODED VIEW . F. Replace with spray tip specified in the GENERAL section of MODEL SPECIFICATIONS . G. See PUMP TROUBLESHOOTING . H. Straighten hose. I. Clean water filter screen or hose inlet screen. J. See "Pump engine starts slow or overheats and stops". K. Tighten all fittings. L. See PUMP TROUBLESHOOTING . M. If a water leak is found, DO NOT OPERATE THE MACHINE . Disconnect the power and replace hose. N. Resupply chemical, place soap screen in water, or shut off metering valve. O. Repair or replace unloader valve. P. Open inlet ball valve completely. (Handle parallel w/valve body). Q. See COIL BACK PRESSURE CHECK on MACHINE MAINTENANCE .

CLEANER TROUBLESHOOTING (CONT.)

ELECTRIC DRIVEN HOT WATER CLEANERS

TROUBLE	POSSIBLE CAUSE	REMEDY
4. Excessive, unusual noise.	A. Pump B. Defective engine. C. Pulleys rubbing. D. Misalignment of pump & engine	A. See PUMP TROUBLESHOOTING . B. Call service technician or take engine to Repair/Warranty station. C. Adjust shields or pulley(s). D. Realign pump and engine.
5. Belts slipping.	A. Belts too loose. B. Excessive Back Pressure. C. Defective Water Pump.	A. Tighten belt per instructions on MACHINE MAINTENANCE . B. See "Excessive Back Pressure" C. See PUMP SERVICE .
6. Excessive Back Pressure	A. Spray tip built up with lime. B. Water pump turning too fast. C. Coil built up with lime. D. Relief valve defective.	A. Remove and clean, or replace spray tip with tip specified in the GENERAL section of MODEL SPECIFICATIONS . Flush machine per FLUSHING in MACHINE MAINTENANCE . B. See MODEL SPECIFICATIONS . C. Delime coil. D. Remove and replace.
7. Excessive vibration.	A. Defective Belt. B. Defective Pump. C. Defective accumulator	A. Remove and replace using belt specified in CLEANER EXPLODED VIEW or the GENERAL section of MODEL SPECIFICATIONS . B. See PUMP TROUBLESHOOTING . C. Recharge/Replace.
8. Engine will not start	A. No Fuel B. Plugged fuel filter. C. Water in fuel D. Defective or corroded battery cable. E. Defective engine	A. Replenish fuel per owners manual. B. Change fuel filter. C. Drain and replenish fuel. D. Clean cables and cable ends. E. Call service technician.
9. Engine will not turn over.	A. Pump frozen B. Defective engine. C. Defective water pump D. Excessive back pressure	A. Machine must be thoroughly warmed to above freezing. B. Call service technician or take engine to Repair/Warranty station. C. See PUMP SERVICE . D. See "Excessive Back Pressure"
10. Engine starts slow or overheats and stops.	A. Improper fuel. B. Excessive back pressure. C. Defective engine. D. Dirt in fuel line or filters. E. Incorrect oil level. F. Dirty air cleaner. G. Faulty spark plug. H. Engine overloaded.	A. See "Low voltage". B. See "Excessive Back Pressure". C. Call service technician. D. Clean and replace fuel filters. E. Check oil level per engine owners manual. F. Change air filters per engine owners manual. G. Change spark plug and set gap per engine owners manual. H. See "Excessive Back Pressure".
11. Engine operates erratically knocks or pings.	A. Improper fuel. B. Dirt in fuel line or filter. C. Dirty air cleaner. D. Faulty spark plug. E. Engine overloaded.	A. Replenish fuel as specified in engine owners manual. B. Clean and replace fuel filters. C. Change air filters per engine owners manual. D. Change spark plug and set gap per engine owners manual. E. See "Excessive Back Pressure".

OIL FIRED WATER HEATER TROUBLESHOOTING

TROUBLE	POSSIBLE CAUSE	REMEDY
1. Machine will not rise to operating temperature	A. Low fuel pressure. B. Water in fuel piping. C. Fuel filter clogged. D. Poor combustion. E. Improper fuel supply. F. Temperature control inoperative (if equipped).	A. See BURNER on MODEL SPECIFICATIONS for specified pressure. B. Drain fuel tank and remove and replace filter per FUEL FILTER INSERT . C. Remove and replace fuel filter element per FUEL FILTER INSERT . D. See "Poor combustion". E. Use fuel specified in "BURNER" section of the MODEL SPECIFICATIONS . F. See TEMPERATURE CONTROL INSERT .
2. Machine overheats	A. Insufficient water. B. Temperature control inoperative. C. Improper fuel supply	A. See Low Operating Pressure on MACHINE TROUBLESHOOTING INSERT . B. See TEMPERATURE CONTROL INSERT . C. Use fuel specified in "BURNER" section of the MODEL SPECIFICATIONS .
3. Dry steam (very little moisture, very hot steam)	A. Insufficient water. B. Improper fuel supply. C. Improper fuel pressure.	A. See Low Operating Pressure on MACHINE TROUBLESHOOTING INSERT . B. Use fuel specified in BURNER section of the MACHINE SPECIFICATIONS . C. See BURNER on MODEL SPECIFICATIONS for specified pressure.
4. Machine smokes (sweet smelling exhaust)	A. Improper fuel supply. B. Insufficient combustion air. C. Leaking fuel system. D. Clogged or improper burner nozzle. E. Loose burner nozzle.	A. Use fuel specified in BURNER section of MODEL SPECIFICATIONS . B. See AIR BAND ADJUSTMENT on OIL BURNER MAINTENANCE INSERT . C. Correct leakage problem. D. Remove (DO NOT CLEAN) and replace nozzle per BURNER ASSEMBLY INSERT . E. See BURNER MAINTENANCE INSERT .
5. Machine fumes (exhaust burns eyes)	A. Too much combustion air. B. Improper fuel pressure.	A. See BURNER TROUBLESHOOTING INSERT . B. See FUEL on MODEL SPECIFICATIONS for specified pressure.
6. Excessive oil dripping from laydown coil condensate.	A. Loose nozzle. B. Fuel pressure too high. C. Burner nozzle defective. D. Incorrect burner nozzle.	A. See BURNER TROUBLESHOOTING INSERT . B. See FUEL PRESSURE ADJUSTMENT section on BURNER MAINTENANCE INSERT . C. Remove and replace with appropriate nozzle found on the BURNER ASSEMBLY OR BREAKDOWN INSERT . D. Remove and replace with appropriate nozzle found on the BURNER ASSEMBLY OR BREAKDOWN INSERT .
7. Poor combustion.	A. Low fuel pressure. B. Improper fuel supply. C. Insufficient combustion air.	A. See Low Fuel Pressure on BURNER TROUBLESHOOTING INSERT . B. See Low Fuel Pressure on BURNER TROUBLESHOOTING INSERT . C. See AIR BAND ADJUSTMENT section on OIL BURNER MAINTENANCE .

EXPLODED VIEW - P/N 5405-01121




10-27-05 Z08-05262

VALVE, FLOAT
P/N C03-00636

SPECIFICATIONS

• MAXIMUM FLOW	14 GPM / 53 LPM / 35 PSI
• MATERIAL - HOUSING	BRASS
• MATERIAL - WATER SEAL	BUNA - N
• MATERIAL - PLUNGER	FLUTED CELCON
• WEIGHT	0.82 LBS. / 0.37 GM
• INLET	1/2 MIP




PART LISTS

ITEM	PART NUMBER	PART DESCRIPTION	QTY.
1	BODY	HOUSING, VALVE	1
2	ANGLE	ARM, PLUNGER	2
3	BOLT	SCREW, WING	1
4	Part14	ARM, BALL	1
5	PLUNGER	PLUNGER	1
6	U PEICE	LINK,PLUNGER	1

ASSEMBLY, CHASSIS - SPLIT

EXPLODED VIEW - P/N 8305-05105



PART LISTS


ITEM	PART NUMBER	PART DESCRIPTION	QTY.
1	4120-00116	WELDMENT, HEAD - BURNER	1
2	4205A-00111	WELDMENT, COIL - 18"	1
3	550-00117	WELDMENT, HEAD - EXHAUST	1
4	AS1693008PBR	WRAPPER, CHASSIS - LOWER	1
5	AS1693011PBR	WRAPPER, COIL 20 1/2 x 27	1
6	E06-00002-3	COUPLING, HALF	2
7	E15-00055-9	NIPPLE, 1/2MNPT	1
8	H04-19011	SCREW, SELF TAP - 10-16 X 5/8	10
9	Z01-05001	INSULATION, CERAMIC	1
10	Z01-05005	INSULATION, CERAMIC	1

GENERAL PUMP MAINTENANCE

OIL LEVEL

CHECK THE OIL LEVEL BY UNSCREWING DIPSTICK.
THE LEVEL SHOULD BE BETWEEN THE 2 MARKS.

OIL LEVEL IS ALSO SHOWN IN THE
ROUND INDICATOR.




TOOL KITS

PACKING EXTRACTION KIT - P/N Z09-00028

COMPLETE TOOL KIT - P/N Z09-00021

VALVE SERVICE


1. Remove the plugs holding the valve assemblies.
2. Remove and discard o-rings from the plugs. Clean plugs with solvent or soap and water. Allow to dry.
3. Using a needle nose pliers, fingers, or hook shaped tool, remove the valve assemblies from the head. Remove and discard the o-rings from the valve assemblies and/or head. Examine each valve assembly and discard damaged parts. Refer to the "**PUMP BREAKDOWN**" for part numbers of any replacement items.
4. Clean any accumulated debris from the valve cavities and flush with water.
5. Wash the valve assemblies in clean water and rinse. While still wet, test each valve assembly by sucking on the valve seat. A properly sealing valve will allow a good vacuum to be developed and maintained, while a malfunctioning valve will not. Good valve assemblies should be set aside for installation in step 7.



6. Malfunctioning valve assemblies must be replaced.
7. Lubricate a new o-ring with the pump crankcase oil and install into valve cavity in the head. Install a good valve assembly into the cavity as illustrated.
8. Lubricate a new o-ring with pump crankcase oil and place on a plug cleaned in step 2 above.
9. Install a plug into the pump head. Tighten plug by hand.
10. Torque the plug to the value indicated in the "TORQUE" section of the pump specifications.
11. Repeat steps 7 through 11 for remaining valve assemblies.


HEAD REMOVAL

1. Remove the cap screws holding the pump head to the crankcase. A metric tool is required for this step. Be careful not to lose the washer on each cap screw.
2. Remove the head by rotating the crankshaft and tapping the head away from the crankcase with a soft mallet. Keep rear surface of the head parallel to the front surface of the crankcase to prevent binding on the plungers.
3. Once the head is removed, protect the plungers from damage.



ASSEMBLY, PUMP

EXPLODED VIEW - P/N 5357-00501




PART LISTS

ITEM	PART NUMBER	PART DESCRIPTION	QTY.
1	4355EB-00513	MOUNT, PUMP	1
2	C03-00810	VALVE, AIR	1
3	C09-00008	VALVE, EASY START	1
4	E04-00002-58	BUSHING, PIPE	1
5	E04-00016-58	BUSHING, PIPE	1
6	E06-00085-48	FITTING, ADAPTER	1
7	E07-00006-5	CROSS, PIPE - HIGH PRESSURE	1
8	E08-00011-58	ELBOW, PIPE	1
9	E10-00018-4	TEE, STREET	1
10	E10-00021-58	TEE, STREET	1
11	E14-00010-68	NIPPLE, PIPE - HEX	1
12	F04-00765	SWITCH, PRESSURE	1
13	N07-00060	PUMP, WATER - TS1021	1
14	W02-10016-8	BARB, HOSE	1
15	W02-10026-8	BARB, HOSE	1
16	W02-10036-8	BARB,HOSE	1
17	Z02-01013-2	HOSE, POLYBRAID - 1/4 X 10	1

GENERAL PUMP MAINTENANCE

PLUNGER SERVICE

1. Remove pump head per "HEAD REMOVAL".
2. Remove any packings and retainers left on the plungers by pulling them straight off.
3. Examine each plunger, looking for a smooth surface free of any scoring, cracks, or pitting. Any defective plungers should be removed per "PLUNGER REMOVAL".
4. Discard and replace any defective plungers.
5. Reinstall the plunger per "PLUNGER INSTALLATION".
6. Reinstall head per "HEAD INSTALLATION".



PLUNGER REMOVAL

NOTE: When the plunger screw is removed, it is important to install new o-ring, anti-extrusion, and copper washers.

1. Remove the plunger screw is removed, it is important to install new o-ring, anti-extrusion, and copper washers.
2. Remove the plunger retaining screw by turning counterclockwise. Remove and replace copper washer.
3. Remove and discard o-ring and anti-extrusion ring from retainer screw.
4. Remove the plunger from the cross head and examine it for cracks, scoring, or pitting.
5. Remove and discard copper flinger washer, clean with solvent and allow to dry.

PLUNGER INSTALLATION

1. Install the copper flinger washer onto the cross head.
2. Slide the plunger onto the crosshead.
3. Lubricate an o-ring with crankcase oil and install into the groove on the plunger screw. Install the anti-extrusion ring into the groove next to the o-ring. Note: The o-ring should be nearest the screw head and the anti-extrusion ring nearest the threads.
4. Apply a drop of thread sealant to the threads of the retainer screw.
5. Thread the plunger retainer screw into the cross head making sure the copper flat washer is installed onto the screw.
6. Torque the plunger retainer screw to the value indicated in the torque section of the pump specifications.


PACKING SERVICE

1. Remove the head per "PUMP HEAD REMOVAL".
2. Remove any packings and female adapters left on the plungers by pulling them straight off. Insert proper packing extractor onto the extractor hammer. Insert packing extractor and tool through the packings and adapters remaining in the head. Tighten the hammer and remove the remaining items in the head. Remove packings and o-rings from adapters. Discard the o-rings and packings.
3. Clean the packing canities in the head and rinse with clean water.
4. Clean exposed plungers. Clean male and female adapters with soap and water and allow to dry.
5. Examine male and female adapters, discard worn items. Trial fit the female adapters into the head

GENERAL PUMP MAINTENANCE



checking for binding or damage. Discard and replace damaged items.

6. Lubricate packing cavities in the head and all packings and adapters with pump crankcase oil.
7. Lay head on the bench with packing cavities up. Install one male adapter in each cavity with the flat side down.
8. Install one v-packing into each cavity with the lips pointing down. A packing insertion too of the appropriate size is recommended for this operation.
9. Install the restop ring with the lips pointing down.
10. Install a front female adapter into each cavity with the flat side up. Make certain the adapter goes all way down into the cavity.
11. Install the low pressure packing with the flat side down.
12. Install the rear female adapter into each cavity with the lips pointing down.
13. Lubricate o-rings with pump crankcase oil and install one into the groove of each adapter.
14. Install one adapter and o-ring into each cavity with the flat side up. Each adapter and o-ring assembly should push into the head to approximately 1/16 inch of being flush with the surface of the head. Only hand pressure should be required to perform this operation. This step is **VERY IMPORTANT**. If the rear female adapter does not fit almost flush, something is not properly positioned. If a proper fit is obtained, proceed to step 16. If a proper fit is not obtained, remove the female adapters from the offending cavity and reinstall items per steps 8 through 15.
15. Install head per "HEAD INSTALLATION".



HEAD INSTALLATION

1. Prepare pump head per instructions in "PACKING SERVICE".
2. Rotate the plungers so the outer plungers are projecting the same distance from the crankcase.
3. Lubricate the exposed plungers with crankcase oil.
4. Start the head onto the plungers and using a soft mallet, tap the head evenly until it comes in contact with the crankcase.
5. Start the cap screws through the head and into the crankcase. Do not forget the lock washer on each screw.
6. Tighten all cap screws by hand.
7. Torque the cap screws to the value indicated in the "TORQUE" section of **PUMP SPECIFICATIONS**. Torque the cap screws in the order listed below.



PUMP MAINTENANCE RECORD

OIL CHANGE

MONTH / DAY / YEAR	OPERATING HOURS	OIL BRAND & TYPE

PUMP SERVICE

MONTH / DAY / YEAR	OPERATING HOURS	TYPE OF MAINTENANCE

PUMP TROUBLESHOOTING

<i>TROUBLE</i>	<i>POSSIBLE CAUSE</i>	<i>REMEDY</i>
1. Oil leaking in the area of water pump crankshaft.	A. Worn crankshaft seal. B. Bad bearing. C. Grooved shaft. D. Failure of retainer o-ring	A. Remove and replace. B. Remove and replace. C. Remove and replace. D. Remove and replace.
2. Excessive play on crankshaft.	A. Defective bearings. B. Excess shims.	A. See "Worn bearing". B. Set up crankshaft.
3. Loud knocking in pump.	A. Loose connecting rod screws. B. Worn connecting rod. C. Worn bearings. D. Loose plunger bushing screw.	A. Tighten connecting rod screws per PUMP SPECIFICATIONS . B. Replace connecting rod per PUMP MAINTENANCE . C. Replace bearings per PUMP MAINTENANCE . D. Tighten plunger screw per PUMP SPECIFICATOINS .
4. Oil leaking at the rear portion of the pump.	A. Damaged or improperly installed oil gauge window gasket. B. Damaged or improperly installed rear cover. C. Oil gauge loosed. D. Rear cover screws loose. E. Pump overfilled with oil, displaced through crankcase breather hole in oil cap/dipstick.	A. Replace gasket or o-ring. B. Replace gasket or o-ring. C. Tighten oil gauge. D. Tighten rear screws. to torque values in PUMP SPECIFCATIONS. S E. Drain oil: refill to recommended oil level as stated in OIL LEVEL in PUMP MAINTENANCE .
5. Water in crankcase	A. May be caused by humid air condensing into water inside the crankcase. B. Worn or damaged plunger screw o-ring.	A. Maintain or step up lubrication schedule. B. Remove and replace. See PLUNGER SERVICE in PUMP MAINTENANCE .
6. Worn bearing	A. Excessive belt tension. B. Oil contamination.	A. See BELT TENSION in MACHINE MAINTENANCE . B. Check oil type and change intervals per PUMP SPECIFICATIONS .
7. Short bearing life	A. Excessive belt tension. B. Misalignment between pump and motor. C. Oil has not been changed on regular basis.	A. See BELT TENSION in MACHINE MAINTENANCE . B. Re-align pump and motor. C. Check oil type and change intervals per PUMP SPECIFICATIONS .
8. Short seal life	A. Damaged plunger bushing. B. Worn connecting rod. C. Excess pressure beyond the pump's maximum rating. D. High water temperature.	A. Replace punger bushing. B. Peplace connecting rod. C. Match pressure stated in PUMP SPECIFICATIONS . D. Lower water tempersture stated in PUMP SPECIFCATIONS .


PUMP TROUBLESHOOTING

<i>TROUBLE</i>	<i>POSSIBLE CAUSE</i>	<i>REMEDY</i>
9. Dirty or worn check valves.	A. Normal wear. B. Debris	A. Remove and replace. B. Check for lack of water inlet screens.
10. Presence of metal particles during oil change.	A. Failure of internal component. B. New pump.	A. Remove and disassemble to find probable cause. B. New pumps have machine fillings and debris and should be drained and refilled per PUMP SPECIFICATIONS .
11. Water leakage from under head.	A. Worn packing. B. Cracked/scored plunger. C. Failure of plunger retainer o-ring.	A. Install new packing. B. Remove and replace plunger. C. Remove and replace plunger retainer o-ring.
12. Loud knocking noise in pump	A. Pulley loose on crankshaft. B. Defective bearing. C. Worn connecting rod. D. Worn crankshaft. E. Worn crosshead.	A. Check key and tighten set screw. B. Remove and replace bearing. C. Remove and replace connecting rod. D. Remove and replace crankshaft. E. Remove and replace crosshead.
13. Frequent or premature failure of the packing	A. Scored, damaged, or worn plunger. B. Overpressure to inlet manifold. C. Abrasive material in the fluid being pumped. D. Excessive pressure and or temperature of fluid being pumped. E. Over pressure of pumps. F. Running pump dry.	A. Remove and replace plungers. B. Reduce inlet pressure. C. Install proper filtration on pump inlet pumping. D. Check pressures and fluid inlet temperature; be sure they are within specified range. E. Reduce pressure. F. Do not run pump without water.
14. Low Pressure	A. Dirty or worn check valves. B. Worn packing. C. Belt slipping. D. Improperly sized spray tip or nozzle. E. Inlet filter screen is clogged. F. Pitted valves.	A. Clean/Replace check valves. B. Remove and replace packing. C. See BELT TENSION in MACHINE MAINTENANCE . D. See MACHINE SPECIFICATIONS for specified spray tip or nozzle. E. Clean inlet filter screen. F. See VALVE SERVICE in PUMP MAINTENANCE .
15. Erratic pressure: pump runs rough	A. Dirty or worn check valves. B. Foreign particles in valve assemblies. C. High inlet water temperature	A. Clean/Replace check valves. A. Clean/Replace check valves. C. See temperature in PUMP SPECIFICATIONS .
16. Excessive vibration	A. Dirty or worn check valves	A. See "Dirty or worn check valves"
17. Scored plungers	A. Abrasive material in fluid being pumped.	A. Install proper filtration on pump inlet plumbing
18. Pitted plungers	A. Cavitation	A. Decrease inlet water temperature and/or increase inlet water pressure.
19. Cavitation	A. High inlet fluid temperature Low inlet pressure.	A. Lower inlet fluid temperature. Raise inlet fluid pressure.

PUMP, WATER - P/N N07-00060

DIMENSIONS

TS1021
GENERAL



PERFORMANCE

DISCHARGE VOLUME.....5.6 GPM / 21.2 LPM
PUMP HEAD PRESSURE.....3500 PSI / 241.0 BAR

GENERAL

CRANKSHAFT ROTATION.....CLOCKWISE AND COUNTER CLOCKWISE
MAXIMUM SPEED.....1450 RPM
MAXIMUM PUMPED FLUID TEMPERATURE.....165°F / 74°C
INLET PRESSURE.....-9 IN HG @ 75°F TO 116 PSI / -0.3 BAR @ 24°C TO 8 BAR
WEIGHT (WET).....32.0 LBS / 14 KG

LUBRICATION

OIL CHANGE INTERVALAFTER FIRST 50 HOURS THEN AFTER 500 HOURS
OIL TYPE.....SAE 20 OR SAE 30 (NON-DERTERGENT)
CRANKCASE CAPACITY.....40.6 FL OZ / 1.2 LT

TORQUE

VALVE PLUG.....72 FT LBS / 10.0 KG M
MOUNT TO CRANKCASE.....32 FT LBS / 2.2 KG M
CONNECTING ROD CAP TO CONNECTING ROD.....15 FT LBS / 1.6 KG M
* PLUNGER SCREW TO CROSSHEAD.....15 FT LBS / 2.0 KG M
REAR CRANKCASE COVER TO CRANKCASE.....8.0 FT LBS / 1.0 KG M
HEAD TO CRANKCASE.....22.0 FT LBS / 2.0 KG M

*NOTE: WHEN PLUNGER SCREW IS REMOVED, IT IS IMPORTANT YOU INSTALL A NEW COPPER WASHER AND FLINGER WASHER TO ENSURE PROPER FIT AND SEAL OF CERAMIC PLUNGER. EACH TIME PLUNGER SCREW IS TORQUED, COPPER WASHERS CONFORM TO PLUNGER. IF SAME COPPER WASHERS ARE USED, PLUNGER CRACKING OR A POOR SEAL MAY RESULT.


REPAIR PARTS PACKAGES

DESCRIPTION	BREAKDOWN	PART NUMBER	DESCRIPTION	BREAKDOWN	PART NUMBER
VALVE ASSEMBLIES.....	6 OF 39,	N07-99001	MALE ADAPTERS.....	6 OF 31.....	N07-99007
CROSSHEAD SEALS.....	3 OF 47.....	N07-99002	REAR ADAPTERS.....	3 OF 25,26.....	N07-99010
CRANKSHAFT SEALS.....	2 OF 21.....	N07-99003	PLUNGER PACKING.....	1 OF 25 - 31.....	N07-99028
VALVE PLUGS BRASS.....	6 OF 40,41.....	N07-99004	V PACKINGS (W/RESTOP)..	3 OF 27,29,30.....	N07-99069
* PLUNGER SCREWS.....	3 OF 42,43,14,44,46.....	N07-99006	V PACKINGS.....	3 OF 30,27.....	N07-99008
* PLUNGER WASHERS.....	3 OF 43,14,44,46.....	N07-99006A	FRONT ADAPTER.....	3 OF 28,29.....	N07-99071

BREAKDOWN, PUMP - N07-00060

EXPLODED VIEW

TS1021




PARTS LIST

ITEM	PART NO.	DESCRIPTION	ITEM	PART NO.	DESCRIPTION
1	N07-40018	SCREW, CAP	25	N07-40016	O-RING
2	N07-40020	RETAINER, BEARING - CLOSED	26	N07-40015	ADAPTER, FEMALE - REAR
3	N07-40021	O-RING	27	N07-40012A	PACKING, V - LOW PRESSURE-20MM
4	N07-60022	BEARING, ROLLER	28	N07-34013	ADAPTER, FEMALE - FRONT
5	N07-40024	DIPSTICK, OIL	29	N07-40062	RING, RESTOP
6	N07-40023	CRANKCASE	30	N07-40012	PACKING, V - HIGH PRESSURE
7	N07-60038	CROSSHEAD	31	N07-99007	KIT, ADAPTER - MALE 20MM
8	N07-40034	ROD, CONNECTING	32	N07-20049	PLUG, PIPE
9	N07-70025	O-RING	33	N07-20050	PLUG, PIPE
10	N07-16026	COVER, REAR - O-RING	34	N07-20051	WASHER, FLAT
11	N07-60027	SCREW, CAP	35	N07-20011	WASHER, FLAT
12	N07-20029	INDICATOR, OIL LEVEL	36	N07-40001	HEAD, PUMP - BRASS
13	N07-20030	PLUG, PIPE	37	N07-40003	WASHER, FLAT - COPPER
14	N07-20028	O-RING	38	N07-40002	SCREW, CAP
15	N07-40032	PIN, CROSSHEAD	39	N07-99001	KIT, VALVE ASSEMBLY
16	N07-40053	RING, RETAINING	39A	N07-20004	O-RING
17	N07-60031	CRANKSHAFT	40	N07-20009	O-RING
18	N07-40033	KEY	41	N07-20010	PLUG, PIPE
19	N07-40019	RETAINER, BEARING - OPEN	42	N07-20043	SCREW, PLUNGER
20	N07-40035	SHIM	43	N07-20042	WASHER, FLAT
21	N07-40045	SEAL, OIL	44	N07-20041	RING, ANTI-EXTRUSION
22	N07-40046	MOUNT, PUMP	45	N07-40040	PLUNGER - 20MM
23	N07-40047	WASHER, LOCK	46	N07-20039	WASHER, FLINGER - COPPER
24	N07-40048	SCREW, CAP	47	N07-99002	KIT, OIL SEAL

ASSEMBLY, UNLOADER

EXPLODED VIEW - P/N 5357-00515



PART LISTS

ITEM	PART NUMBER	PART DESCRIPTION	QTY.
1	Y01-00123	ACCUMULATOR	1
2	4355EB-00514	BRACKET, UNLOADER - VALVE	1
3	W02-10040-8	BARB, HOSE	1
4	E07-00006-5	CROSS, PIPE - HIGH PRESSURE	1
5	E08-00010-5	ELBOW, PIPE	1
6	E08-00011-58	ELBOW, PIPE	1
7	E14-00010-68	NIPPLE, PIPE - HEX	1
8	C03-00518	VALVE, RELIEF	1
9	C07-03800	VALVE, UNLOADED-BLACK SPRING 3/8FNPT 7.8GPM @ 4200PSI	1

VALVE, UNLOADER - C07-03800

SPECIFICATIONS

MAX FLOW.....7.8 GPM / 30 LPM
 MAXIMUM UNLOADING PRESSURE.....4200 PSI / 290 BAR
 MAXIMUM TEMPERATURE.....190°F / 88°C
 WEIGHT.....2.1 LBS / 0.91 KG
 BYPASS.....1/4 NPT
 INLET & DISCHARGE.....3/8 NPT

REPAIR PARTS PACKAGE

* P/N C07-03700KA - INCLUDES 1 EACH OF ITEMS:
 6, 13, 21, 24, TWO OF 9 & THREE OF ITEM 5

ACCESSORIES

Y02-00009.....0 TO 1500 PSI / 103 BAR GAUGE
 Y02-00002.....0 TO 2000 PSI / 138 BAR GAUGE
 Y02-00010.....0 TO 5000 PSI / 345 BAR GAUGE

PARTS LIST


ITEM	PART NO.	DESCRIPTION
1	C07-03700-7	NUT, LOCK - M8
2	C07-03700-8	KNOB, ADJUSTMENT
3	C07-03700-9	FOLLOWER, SPRING
4	C07-03700-11	GUIDE, PISTON
* 5	C07-02300-08	O-RING
* 6	8RS6-000SV01	O-RING
7	C07-03700-26	PISTON
8	C07-03700-15	PIN, SPRING
* 9	C07-03700-28	RING, ANTI-EXTRUSION
10	C07-0370019A	PLUG - 3/8
11	C07-0370019B	GASKET, WASHER
12	C07-0370018B	HOUSING - 3/8
* 13	N07-20028	O-RING
14	C07-03700-21	SEAT
15	C07-03700-23	SPRING, COMPRESSION
16	C07-03800-24	GUIDE, BALL
17	C07-02000-18	BALL
18	C07-03700-1	GUIDE, ORIFICE
19	C07-03700-3	SPRING, COMPRESSION
20	C07-03700-4	ORIFICE, SHUTTER
* 21	C07-02000-20	O-RING
22	C07-03700-6B	GASKET, WASHER
23	C07-03700-6A	PLUG - 1/4
* 24	C07-03700-29	O-RING
25	C07-03700-12	RING, ANTI-EXTRUSION
26	C07-0370010D	SPRING, COMPRESSION - BLACK
27	C07-03700-25	NUT, HEX - M8

UNLOADING ADJUSTMENT


1. INSTALL APPROPRIATE PRESSURE GAUGE IN PUMP HEAD OUTLET. THE GAUGE SHOULD HAVE A PRESSURE RANGE OF TWICE THE OPERATING PRESSURE.
2. LOOSEN NUT (1) AND TURN KNOB COUNTER CLOCKWISE UNTIL MINIMUM SPRING TENSION.
3. OPEN TRIGGER GUN, START PUMP, AND OBSERVE PRESSURE GAUGE READING. SLOWLY TIGHTEN KNOB CLOCKWISE UNTIL DESIRED OPERATING PRESSURE.
4. CLOSE AND OPEN TRIGGER GUN TO CHECK UNLOADING PRESSURE AND BYPASS FUNCTION OF UNLOADER VALVE. UNLOADING PRESSURE SHOULD NOT EXCEED OPERATING PRESSURE BY MORE THAN 400 PSI.
5. LOCK SETTING BY TIGHTENING LOCK NUT (1).

NOTE: ONCE OPERATING PRESSURE IS REACHED, TURNING CLOCKWISE INCREASES UNLOADING PRESSURE ONLY.

EXPLODED VIEW



ASSEMBLY, CONTROL PANEL
EXPLODED VIEW - P/N 5357-00401




PARTS LIST

ITEM	PART NO.	DESCRIPTION	ITEM	PART NO.	DESCRIPTION
1	V00-17379-2	BURNER, OIL	4	V04-00308	FILTER, FUEL
2	E13-00040-2	NIPPLE, PIPE	5	E08-00006-2	ELBOW, PIPE
3	W02-10019-8	BARB, HOSE			

BREAKDOWN, OIL BURNER - 115V W/SOLENOID

P/N V00-17379-2 - EXPLODED VIEW

#173-111




PARTS LIST

ITEM	PART NO.	DESCRIPTION	ITEM	PART NO.	DESCRIPTION
1	V00-13360	SCREW, THREAD CUTTING	18	V00-13279	COUPLING, SHAFT
2	V00-13038	CLIP, HOLD DOWN	19	V-100714-001	PUMP, FUEL - DANFOSS
3	F04-00517	BOX, JUNCTION	20	F04-00974	SOLENOID, OIL - 115V
4	H04-19000	SCREW, THREAD CUTTING	20A	V13-00653	COIL, SOLENOID - 230V
5	H04-16401	SCREW, MACHINE	21	V00-13064-1	CONNECTOR, FLARE
6	F04-00512	COVER, JUNCTION BOX	22	V00-02668	BAND, AIR - OUTER
7	F04-00315	NUT, HEX	23	V00-02669	BAND, AIR - INNER
8	H05-87500	WASHER, FLAT	24	-----	HOUSING, FAN
9	V00-21659	TRANSFORMER, IGNITION	25	V00-30535-43	ASSEMBLY, BURNER GUN
10	V00-13045	SCREW, THREAD CUTTING	26	V00-13003	CONE, AIR - 3 9/16
11	F04-00316	NIPPLE, CHASE	27	V00-12484	GASKET, FLANGE
12	F04-00310	CONNECTOR, CONDUIT	28	-----	WELDMENT, AIR TUBE
13	F05-12310	CONDUIT, ELECTRICAL	29	V00-12699	SCREW, THREAD CUTTING
14	V00-13392	COVER, SLOT	30	H04-31302	SCREW, SET
15	V00-14296	NUT, HEX	31	V00-20289	FAN W/ITEM 30
16	H04-31310	SCREW, CAP	32	V00-21126	MOTOR, ELECTRIC - 1/4HP 115V
17	V00-14451	ASSEMBLY, OIL LINE	33	V00-13121	STRAIN RELIEF, CORD

ASSEMBLY, BURNER GUN

EXPLODED VIEW - P/N V00-30535-43

30535-043



PARTS LIST

ITEM		DESCRIPTION	ITEM	PART NO.	DESCRIPTION
1	V-100631-001	ASSEMBLY, ELECTRODE - RH	7	V-100632-001	ASSEMBLY, ELECTRODE - LH
*1A	-----	STEM, ELECTRODE - RH	*7A	-----	STEM, ELECTRODE - LH
1B	V00-12574	INSULATOR, ELECTRODE	7B	V00-12574	INSULATOR, ELECTRODE
1C	V00-12231	BAR, BUSS - 2" STRAIGHT	7C	V00-12231	BAR, BUSS - CURVED
1D	V00-13110	NUT, PAL	7D	V00-13110	NUT, PAL
2	V00-12408	BUSHING, INSULATOR	8	V00-13407	PLATE, BAFFLE - 2"
3	V00-12694	SCREW, MACHINE	9	V00-14310	SUPPORT, ELECTRODE
4	H04-19002	SCREW, SET	10	V00-14442	SPRING, ELECTRODE SUPPORT
5	V00-12695	SCREW, MACHINE	11	H04-16400	SCREW, THREAD CUTTING
6	V00-21410-13	ASSEMBLY, OIL PIPE	12	V00-12988	ADAPTER, NOZZLE

*ELECTRODE STEMS AVAILABLE IN ELECTRODE ASSEMBLIES ONLY


OIL BURNER MAINTENANCE

OIL FIRED CLEANERS

AIR BAND ADJUSTMENT

NOTE: The air band adjustment on this burner has been preset at the factory (elevation approximately 1400 feet). On equipment installed where elevation is substantially different, the air band(s) must be readjusted.


1. Loosen the cap screw retaining the air bands.
2. Move the air bands as indicated below with the machine in operation.
NOTE: The air band should be set so the exhaust gives the smoke spot specified in the GENERAL section of the **MACHINE SPECIFICATIONS** on a Shell-Bacharach scale. If a smoke tester is not available, a smoky exhaust, oily odor, or sweet smell indicates insufficient air while eye-burning fumes indicate too much air.
3. Tighten the cap screw retaining the air bands.



FUEL PUMP FILTER SUNDSTRAND PUMP

1. Shut off fuel supply.
2. Loosen the 4 screws holding the cover to the fuel pump housing.
3. Take cover and cover gasket off and pull strainer off of pump housing.
4. Clean out any dirt remaining in the bottom of strainer cover. If there is evidence of rust inside of the unit, be sure to remove water in supply tank and fuel filter.
5. Turn on fuel supply. Failure to do so will result in fuel pump damage.


PART NUMBER
V00-14283-5



PART NUMBER
V00-14283-2

DANFOSS PUMP

1. Shut off fuel supply.
2. Loosen the 2 screws with 7/64 allen wrench one turn.
3. Turn cover counter clockwise and pull strainer and cover off of pump housing.
4. Clean out any dirt remaining in the bottom of strainer cover. If there is evidence of rust inside of the unit, be sure to remove water in supply tank and fuel filter.
5. Reinstall reverse of removal.
6. Turn on fuel supply.



PART NUMBER
V00-99004

TRANSFORMER TEST

1. Remove burner junction box cover.
2. Turn on burner and make sure ignition transformer is receiving rated voltage.
3. Turn off burner.
4. Loosen screw and swing transformer away from burner gun assembly.
5. Turn on burner.
6. Short the high voltage terminals.
CAUTION: Use screwdriver with a well insulated handle to avoid shock.
7. Open gap by drawing screwdriver away from one electrode while touching the other.
8. The spark should jump between 5/8 inches and 3/4 inches, if it doesn't jump, replace the transformer.
9. Turn burner off.
10. Partially close transformer. Check if buss bars align and contact transformer electrodes. If buss bars do not contact, see Buss Bar Alignment.
11. Close transformer, reposition retainer clip and tighten screw



OIL BURNER MAINTENANCE

OIL FIRED CLEANERS

BUSS BAR ALIGNMENT

1. With burner off, loosen screw and swing the transformer away from burner gun assembly.
2. Inspect the buss bars and transformer electrodes for pitting or corrosion.
3. Partially close the transformer. Check if the buss bars contact and are in alignment with transformer electrodes.
4. Proper adjustment is obtained by gently bending the buss bars until they spring against, parallel, and are in full contact with the transformer electrodes.
5. With buss bars aligned, carefully close and fasten the transformer.



7. Partially close transformer. Check if buss bars align and contact the transformer electrodes. If buss bars do not contact, see Buss Bar Alignment.
8. Close transformer, reposition retainer and tighten screw.

ACCESSORIES

Z01-00095 – Fuel Nozzle Changing Wrench
Z01-00092 – Fuel Pump Wrench (Sundstrand)
Z01-00093 – Solenoid Wrench (ASCO)


ELECTRODE ASSEMBLY ADJUSTMENT

1. Loosen screws holding electrode assemblies.
2. Raise electrode tips $5/32$ inches above surface plane or end of oil nozzle.
3. Place each electrode tip $5/16$ inches from center of spray nozzle hole, maintaining previous measurement.
4. Spread electrode tips to $1/8$ -inch gap maintaining previous measurements.
5. When the proper measurements are obtained, gently tighten screws that hold electrode assembly in place. **CAUTION:** Do not over tighten, as this will cause the electrode insulator to fail.

BURNER GUN REMOVAL & INSTALLATION

1. Disconnect the fuel line from the burner gun assembly oil line fitting. Loosen the other end of the line and swing line out of the way.
2. Remove the retaining nut.
3. Loosen screw and swing transformer away from burner gun assembly.
4. Carefully remove the burner gun assembly.
 - A. Check and replace electrode insulators if cracked.
 - B. Clean burnt buss bars.
 - C. Clean carbon off electrodes.
 - D. Clean carbon off oil nozzle. (Use caution not to scratch face of nozzle or orifice.)
 - E. Check for a loose oil nozzle. **NOTE:** Check with dealer and/or replace nozzle with proper nozzle.
5. Gently replace burner gun assembly in air tube. **CAUTION:** Do not force. Forcing will cause electrode misalignment
6. Reinstall the retaining nut.

Reinstall the oil line making sure both ends are tight.



OIL FIRED BURNER TROUBLESHOOTING


TROUBLE	POSSIBLE CAUSE	REMEDY
1. Burner will not ignite.	A. Electrodes out of alignment. B. Electrode insulator failure. C. Water flow switch not closing. D. Vacuum switch not closing. E. Temperature control switch not closing. F. Fuel solenoid valve not opening. G. Weak transformer. H. Faulty cad cell (if equipped). I. Faulty primary control (if equipped). J. Burner motor thermal protector locked out. K. Wiring. L. Burner switch. M. Pump pressure. N. Venting. O. Sooting. P. No fuel	A. See "ADJUSTING ELECTRODE ASSEMBLY" in BURNER MAINTENANCE SECTION. B. Remove and replace if there are breaks, cracks, or spark trails. C. Adjust, repair, or replace switch. D. Adjust, repair or replace switch. E. Adjust or replace the TEMPERATURE CONTROL. F. Clean, repair, or replace solenoid. G. Clean and check transformer terminals. Check transformer for spark per "TRANSFORMER TEST" in BURNER MAINTENANCE SECTION. H. Clean and test cad cell, replace if required. I. Replace primary control. J. See "Burner motor thermal protector locked out." K. All wire contacts are to be clean and tight. Wire should not be cracked or frayed. L. Test switch operation. Remove and replace as necessary. M. See "Low fuel pressure". N. A downdraft will cause delayed ignition. Soot deposits on the coil and burner can interrupt air flow, and cause shorting of the electrodes. Clean as required. O. Soot deposits on the coil and burner can interrupt air flow, and cause shorting of the electrodes. Clean as required. P. See "No fuel."
2. No fuel	A. Clogged fuel filter. B. Fuel leak. C. Kinked or collapsed fuel line. D. Low fuel pressure. E. Faulty burner oil pump. F. Air leak in intake lines. G. Clogged burner nozzle	A. Remove and replace filter per FUEL FILTER SECTION. B. Repair as necessary. C. Remove and replace fuel line. D. See "Low fuel pressure". E. Adjust pressure or replace. F. Tighten all fittings. G. Remove and replace (Do not clean).
3. Low fuel pressure	A. Clogged fuel filter. B. Clogged fuel pump filter screen. C. Fuel oil too viscous. D. Air leaks in intake lines. E. Kinked or collapsed fuel line. F. Burner shaft coupling slipping. G. Fuel Nozzle worn. H. Faulty oil pump	A. Remove and replace filter per FUEL FILTER page. B. Remove pump cover and clean strainer using a brush and clean fuel oil, diesel oil or kerosene. C. Operate a lighter oil or in warmer area. D. Tighten all fittings. E. Remove and replace. F. Remove and replace. G. Remove and replace with specified nozzle on BURNER ASSEMBLY. H. Remove and replace.

OIL BURNER TROUBLESHOOTING

TROUBLE	POSSIBLE CAUSE	REMEDY
4. Pulsating pressure	A. Partially clogged fuel pump strainer or filter. B. Air leaking around fuel pump cover.	A. Remove and replace strainer per FUEL PUMP FILTER in OIL BURNER MAINTNANCE Section. B. Check fuel pump cover screws for tightness and damaged gasket.
5. Unit smokes	A. Improper fuel. B. Air to burner insufficient. C. Fuel nozzle interior loose. D. Water in fuel. E. Gun out of alignment.	A. Refuel with FUEL specified on MACHINE SPECIFICATIONS. B. See AIR BAND ADJUSTMENT in OIL BURNER MAINTENANCE section. C. Replace nozzle. D. Inspect fuel filter for water presence. E. Bend oil pipe to center burner nozzle.
6. Burner motor thermal protector kicked out.	A. Low voltage. B. Fuel too viscous. C. Fuel pump defective. D. Motor defective.	A. Voltage must match those specified in the BURNER section of MACHINE SPECIFICATIONS section. B. Operate in warmer conditions or with fuel adapted to cold weather conditions. C. Check that fuel pump turns freely. D. Call service technician or take motor to repair/warranty station.
7. Delayed ignition (rumbling, noisy starts)	A. Dirty or damaged electrodes. B. Air adjustment open too far. C. Poor fuel spray pattern. D. Incorrect electrode setting. E. Weak transformer	A. Clean or replace. B. Readjust per AIR BAND ADJUSTMENT in OIL BURNER MAINTENANCE section. C. Remove and replace with fuel nozzle specified in BURNER ASSEMBLY. D. Readjust per ADJUSTING ELECTRODE ASSEMBLY in OIL BURNER MAINTENANCE section. E. See TRANSFORMER CHECK on OIL BURNER MAINTENANCE section
8. Burner does not electrically come on	A. Burner motor reset button tripped. B. High limit temp control reset tripped if so equipped.	A. Reset if necessary. CAUTION: Do not keep hitting the "reset button" if you have oil pressure you are just filling the burner combustion chamber with oil and if ignited will cause an explosion. B. Reset if necessary.

ASS'Y, TRIGGER GUN & WAND

EV - P/N J06-00158-B




PARTS LIST

ITEM	PART NO.	DESCRIPTION
1	J06-00158	VALVE, TRIGGER GUN
2	J06-00104E	ASSEMBLY, WAND - 42"

PARTS LIST

ITEM	PART NO.	DESCRIPTION
3	W04-24225-A	COUPLING, FEMALE


ASSEMBLY, CHEMICAL LINE EV - P/N 4120-00902P



PARTS LIST

ITEM	PART NO.	DESCRIPTION
1	C04-00131	SCREEN, CHEMICAL
2	Z01-08413-2	HOSE, POLY BRAID - 84"

ASSEMBLY, HOSE & COUPLER EV - P/N 2102-00710



PARTS LIST

ITEM	PART NO.	DESCRIPTION
1	W04-31231-B	NIPPLE, COUPLER
2	K02-03150-1	ASSEMBLY, HOSE

BREAKDOWN, TRIGGER GUN - P/N J06-00158

SPECIFICATIONS

MAXIMUM VOLUME.....	10.0 GPM / 37.9 LPM
MAXIMUM PRESSURE.....	5000 PSI / 344.7 BAR
TEMPERATURE RISE.....	300°F / 150°C
WEIGHT.....	1.8 LBS / 0.8 KG
INLET.....	3/8" NPT FEMALE
OUTLET.....	1/4" NPT FEMALE
DISCHARGE FITTING.....	S.S.

REPAIR INSTRUCTIONS

1. Remove screws (Item 1).
2. Remove handle housings.
3. Drive out pin (Item 5).
4. With a small dowel, remove the cam (Item 6) through the backside of the trigger. Replace with new cam.
5. Remove valve retainer (Item 11), springs (Items 13), and ball (Item 14).
6. With a dowel drive out pin (Item 17) and ball seat (Item 15).
7. Assemble in reverse order.

WARNING: DO NOT USE ACID CONCENTRATES THROUGH GUN

WARNING: NEVER SECURE TRIGGER GUN IN AN OPEN POSITION (TRIGGER PULLED BACK) BY MEANS OTHER THAN THE OPERATOR'S HAND, ETC. BODILY HARM MAY OCCUR IF THE OPERATOR LOSES CONTROL OF THE TRIGGER GUN.

CAUTION: ALWAYS ENGAGE TRIGGER SAFETY LATCH (ITEM 8)
WHEN NOT IN USE.

EXPLODED VIEW

GENERAL
YG5000

1

2

3

4

5

6

7

8

9

10


11

<i>PARTS LIST</i>

<i>ITEM</i>	<i>PART NO.</i>	<i>DESCRIPTION</i>	<i>ITEM</i>	<i>PART NO.</i>	<i>DESCRIPTION</i>
*1	J06-00132-19	SCREW, SELF TAP	7	J06-00158-04	TRIGGER
*2	-----	HOUSING, HANDLE - LEFT	8	J06-00158-05	LATCH, SAFETY
3	J06-99158	KIT, REPAIR	*9	-----	HOUSING, HANDLE - RIGHT
4	J06-00158-01	FITTING, DISCHARGE	10	J06-00158-06	FITTING, INTAKE - 3/8 FNPT
5	J06-00158-02	PIN - 5 X 27.5MM	11	J06-00158-11	HOUSING, VALVE - BRASS
6	J06-00158-03	CAM	*J06-99158A		KIT, HANDLES - HOUSING

KIT, BREAKDOWN - P/N J06-99158

NOTE: POSITION PIN WITH CUPPED END TOWARDS BALL.
* ITEM 18 NOT IN KIT - SHOWN FOR POSITION ONLY




PARTS LIST

ITEM	PART NO.	DESCRIPTION	ITEM	PART NO.	DESCRIPTION
11	-----	RETAINER, VALVE	17	-----	PIN, VALVE
12	J06-00158-07	O-RING	18	*J06-00158-09	WASHER, FLAT - 3.2 X 7 X 0.5MM
13	-----	SPRING, COMPRESSION	19	J06-00121-07	O-RING - VITON
14	J06-00121-11	BALL, SS - 5/16"	20	J06-00158-10	WASHER, FLAT - 3.2 X 7.5 X 1.2MM
15	J06-00158-08	SEAT, VALVE			
16	C07-01300-08	O-RING - VITON		+J06-99158B	KIT, O-RING AND SEAT

ASSEMBLY, CONTROL PANEL

EXPLODED VIEW - P/N 5357-00306




PARTS LIST

ITEM	PART NO.	DESCRIPTION	ITEM	PART NO.	DESCRIPTION
1	5357-05301	PANEL, CONTROL	7	F04-00856	SWITCH, THERMOSTAT
2	F07-00020	METER, HOUR	8	10301-00520	ASS'Y, METERING VALVE
3	F04-00700	SWITCH, ROCKER	8A	C03-00307	VALVE, METERING
4	F04-00611-1	TERMINAL, QUICK DISCONNECT	8B	W02-10031-8	BARB, HOSE
5	AS16-90317PB	CLIP, MOUNTING		5357-00322	COVER, CONTROL
6	E06-00003-5	COUPLING, FULL		Z01-018123	EDGING, MINITRIM

PART NUMBER
ES-00559

ES-00559

[illegible]

ELECTRICAL SCHEMATIC

PART NUMBER

ES-00559



DATE: 06-18-03

DRAWN BY: BWK

WHITE	YELLOW
BLACK	GREEN
RED	PINK
BROWN	ORANGE
BLUE	